

lightner

lightner

Macro Deck v1

Manual




INTRODUCTION

The *Macro Deck* is a compact keyboard designed to trigger specific macros using the lighting console's shortcut functionality. It is compatible with both grandMA2 / grandMA3 and ETC Eos systems.

For improved visibility, the Macro Deck features four backlit surfaces for clear and easy identification of each button / toggle switch. Works best with transparent label maker labels.

SCHEMATIC



COMPONENT OVERVIEW

- 5 x Toggle Switches
- 15 x Buttons
- 1 x On / Off Switch
- 1 x Rigging hole suitable for tripods and magic arms

NOTICE

- If the toggle switches are adjusted while the device is powered off using the built-in switch, the corresponding macros will automatically execute once the device is powered back on.
- Keep away from liquids
- Keep away from heat

MACRO ASSIGNMENT

Toggle Switch 1	Toggle Switch 2	Toggle Switch 3	Toggle Switch 4	Toggle Switch 5
Macro 5001 Macro 5002	Macro 5003 Macro 5004	Macro 5005 Macro 5006	Macro 5007 Macro 5008	Macro 5009 Macro 5010

Button 1	Button 2	Button 3	Button 4	Button 5
Macro 5011	Macro 5012	Macro 5013	Macro 5014	Macro 5015

Button 6	Button 7	Button 8	Button 9	Button 10
Macro 5016	Macro 5017	Macro 5018	Macro 5019	Macro 5020

Button 11	Button 12	Button 13	Button 14	Button 15
Macro 5021	Macro 5022	Macro 5023	Macro 5024	Macro 5025

lightner

DEVELOPED BY

Leon Leitner

Lightner-lx.com